


### Typical Installation Instructions

1. Fit cast iron body, complete with outlet spigot, through wall.
2. Dress membrane onto the body flange continuing a short distance into the body as shown.
3. Fit ductile iron membrane clamp collar such that it clamps the membrane all around forming a watertight seal. (Note that for very thin and/or relatively hard membranes it may be necessary to use additional sealant between the body and the membrane to effect a seal).
4. Fit grating onto clamp collar.

© 2007

ISS. No.		DRAWN	R.B.	1/5/07	TITLE GENERAL INSTALLATION DETAIL FOR WF002 - WF024 PARAPET OUTLETS		
C.N. No.		CHECKED					
DATE		APPRVD.					
	MATERIAL	50910039			SCALE	DRG. No.	ISSUE No.
					NTS	<b>INSTAL 39</b>	1

WADE INTERNATIONAL LTD., THIRD AVENUE, HALSTEAD, ESSEX, CO9 2SX.

TEL: 01787 475151 FAX: 01787 475579

e-mail: tech@wade.eu website: www.wade.eu